



WATER PUMP

WASH LIGHT

VIA PRESSURE GAUGE

THROTTLE BUTTON

CHOKER BUTTON

AMMETER

SPEEDOMETER

WATER TEMPERATURE INDICATOR

FUSE

SPARK BUTTON

WIRING HARNESS

IGNITION LOCK

IGNITION WIRING HARNESS

IGNITION COIL

DIMMER SWITCH

STOP LIGHT SWITCH

STARTING MOTOR

GROUND CABLE